

Nikon CoolPix995

Recommended Camera settings For Oneshot360™

- **M-Mode:** When turning the CoolPix995 on, put it in “M” mode by turning the power dial two clicks over from the OFF position.
- **Image Quality:** Set the Image Quality to **FINE** by pressing the “QUAL” button until you see it change from “NORMAL” to “FINE”.
- **Zoom:** Use the Zoom to **exactly** fill the LCD viewer screen with the circular image. Zoom in too much, you will lose part of the field of view. Zoom in too little, you will not get maximum resolution. The OneShot image may not be exactly centered in the LCD screen – this is normal.
- **Flash:** Make sure the pop-up flash is in its “down” position and the “flash disabled” icon is showing on the LCD screen.
- **Focus:** Manually set the Focus to **20 feet**. Hold the “M-focus” button and rotate the command dial until 20 feet is displayed on the LCD.

Note: The button for placing the camera in manual focus mode is the same as that for setting the timer. If you want to use both the timer and a manual focus setting, you must enable the timer first by pressing the “m-focus” button until you see the timer icon in the LCD, and then hold the button down and dial in the focus distance. *Pressing the “M-focus” button again will set camera back to auto focus mode.*

- **Aperture Priority Mode:** Set the camera to aperture priority (“A”) mode. Hold down the “MODE” button and rotate the command dial until the letter “A” appears in the lower left hand corner of the LCD.
- **Aperture:** Select an aperture value of **f6.7**. Rotate the command dial until this value is visible on the LCD.

Take care to watch the shutter speed when in aperture priority mode. If the light level is low, you will need a tripod when the shutter speed is slower than 1/125sec. The shutter speed is displayed on the bottom of the LCD panel between the “A” mode and the “F6.7” display.

Pressing the “MENU” button just above the LCD screen will access a list of additional camera settings. Use the Multi selector button to scroll through the menu and make your selection for the following:

- **White Balance:** Set the white balance to Automatic. This setting is adequate for most shots.



Camera Guide

REMOTEREALITY
4 Technology Drive
Westborough, MA 01581-0756
866-898-1010

- **Metering:** Set the Metering to Matrix Metering, this gives the best results for OneShot360 images.
- **Sharpness:** Set the Sharpness value to "Normal".

Recommended Camera Settings For 360Plus

Because the 360Plus uses 4 images, it is best to make sure that all 4 images have the same exposure. This will ensure the end result will have a continuous tone and density throughout the image. The best way to do this is to use the Exposure Lock option in the camera. To do this, use all of the above settings, then the following:

- Press the menu button to display the shooting options, and press it again to get to page two of the options. The second menu down on page two is EXP. Select this by navigating with the multi Selector button and select *ON* under *AE Lock*. Press the menu button again to complete the selection. You will know the exposure lock is working by the WB-L AE-L display on the LCD.
- After checking the camera settings for Oneshot360, take the first image of the series. Exposure and white balance settings are fixed at the values used in the first image after the AE-Lock has been selected.
- Continue to take the next three images to finish the 360x360 image.
- Before beginning the next 360x360 shot, you should return to the AE-Lock menu and select RESET. This will start a new exposure lock for the current lighting conditions.

You can turn the lock function off to allow the camera to set exposure and white balance separately by going back to the same menu and selecting OFF from the AE-Lock menu.

- Use the bubble level to set the lens mount to a level position before taking the first shot.
- Do NOT re-level between shots. It is normal for the bubble level to shift between shots. Re-leveling is not necessary and not recommended.
- When processing 360Plus images in the RemoteReality software, use the **Nikon 990** camera selection.



Camera Guide

REMOTEREALITY
4 Technology Drive
Westborough, MA 01581-0756
866-898-1010

OPTIONAL MENU SETTINGS

By pressing the "MENU" button just above the color LCD screen, you will have access to a few more settings you may find useful. While in these menus, use the Multi selector button to scroll up and down and to make your selection:

- Under the "SET UP" sub-menu, you may want to change the "AUTO OFF" setting to a longer time period such as 5 minutes. Although this feature helps to save battery life, the default value (30 seconds) may not be enough time to set up for a OneShot360 image, at least until you are more familiar with the process.
- Also under the "SET UP" sub-menu, there is an option called "CONTROLS" which leads to another sub-menu. You may want to check the first three options in this sub-menu. This will maintain the flash setting, and the mode (aperture priority or manual) and focus settings even if you turn the camera on and off between shots. However, you will still have to place the camera in manual focus mode every time you want to use the timer for a shot (because the timer switches off after every shot, and pressing the timer/M-focus button to re-enable the timer switches the camera back in to auto-focus mode).